

Karta Sieciowa Wifi Zenwire Model WD-4605AC

Dziękujemy za zakup karty sieciowej Wifi Zenwire. Życzymy miłego użytkowania!

Instrukcja obsługi:

1. Podłącz urządzenie do portu USB komputera.
2. Upewnij się, że Twoje urządzenie jest kompatybilne z kartą sieciową.
3. Większość urządzeń domyślnie wykrywa sterowniki i produkt powinien działać od razu po podłączeniu,, jeśli mimo to potrzebujesz zainstalować je ręcznie, skorzystaj z linku poniżej by pobrać i zainstalować sterowniki lub za pomocą dołączonej płyty.
<https://zenwire.eu/pl/i/Sterowniki-Drivers/157>
4. Postępuj zgodnie z informacjami na instalatorze sterowników by zainstalować poprawnie sterownik.
5. Urządzenie jest gotowe do działania.

Ostrzeżenia i zalecenia:

1. Pod żadnym pozorem nie wolno otwierać obudowy urządzenia. Nie dokonuj nieautoryzowanych przez producenta napraw.
2. Produkt nie powinien pracować w warunkach zwiększonej wilgotności powietrza, chroń go przed zamoczeniem. Nie narażaj go na ekstremalnie wysokie i niskie temperatury. Chroń go przed uszkodzeniami mechanicznymi. Zalecana praca urządzenia w temperaturze pokojowej.
3. Nie używaj karty sieciowej niezgodnie z jej przeznaczeniem może to skutkować jej uszkodzeniem.
4. Producent nie ponosi odpowiedzialności za niestosowanie się do zaleceń użytkownika przez użytkownika.
5. Trzymaj produkt oraz materiały opakowaniowe z dala od dzieci i zwierząt. Produkt nie jest zabawką.
6. Chroń produkt przed nadmierną ekspozycją słoneczną.
7. Zasięg sieci wifi zależy od otoczenia w której pracuje produkt, zbrojone ściany, elementy w otoczeniu, urządzenia emitujące promieniowanie radiowe i elektromagnetyczne, czy duże odległości mogą spowodować gorszy zasięg lub zakłócenia. W razie problemów z działaniem upewnij się, czy te czynniki nie wpływają na jakość połączenia.

Wymagania systemowe:

- Windows XP / Vista / 7 / 8 / 8.1 / 10 / 11 i nowsze
- Mac od OS 9 / Linux

Email: sklep@zenwire.eu

Producent: Zenwire Sp. Z.o.o. 60-685 Poznań, Wojciechowskiego 6B/133 Wyprodukowano w PRC.



Przedstawiony symbol umieszczony na produktach lub dołączonej do nich dokumentacji informuje, że niesprawnych urządzeń elektrycznych lub elektronicznych nie można wyrzucać razem z odpadami gospodarczymi. Prawidłowe postępowanie w razie konieczności utylizacji, powtórnego użycia lub odzysku podzespołów polega na przekazaniu urządzenia do wyspecjalizowanego punktu zbiórki, gdzie będzie przyjęte bezpłatnie. W niektórych krajach produkt można oddać lokalnemu dystrybutorowi podczas zakupu innego urządzenia. Prawidłowa utylizacja urządzenia umożliwia zachowanie cennych zasobów i uniknięcie negatywnego wpływu na zdrowie i środowisko, które może być zagrożone przez nieodpowiednie postępowanie z odpadami. Szczegółowe informacje o najbliższym punkcie zbiórki można uzyskać u władz lokalnych. Nieprawidłowa utylizacja odpadów w zagrożona jest karami przewidzianymi w odpowiednich przepisach lokalnych.

Użytkownicy biznesowi w krajach Unii Europejskiej

W razie konieczności pozbycia się urządzeń elektrycznych lub elektronicznych, prosimy skontaktować się z najbliższym punktem sprzedaży lub z dostawcą, którzy udzielą dodatkowych informacji.

Pozbywanie się odpadów, w krajach poza Unią Europejską

Taki symbol jest ważny tylko w Unii Europejskiej. W razie potrzeby pozbycia się niniejszego produktu prosimy skontaktować się z lokalnymi władzami lub ze sprzedawcą celem uzyskania informacji o prawidłowym sposobie postępowania.

Uproszczona deklaracja zgodności

Producent oświadcza na swoją wyłączną odpowiedzialność, że niniejszy produkt, którego dotyczy instrukcja jest zgodny z dyrektywą ROHS 2011/65/EU oraz 2015/863 oraz dyrektywą RED 2014/53/EU.

Link do strony internetowej z deklaracjami zgodności producenta:

<https://zenwire.eu/pl/i/Deklaracje-zgodnosci/148>



Zenwire Wifi Card Model WD-4605AC

Thank you for purchasing the Zenwire wifi card. We hope you enjoy using it!

User Manual:

1. Connect the device to the USB port of the computer.
2. Make sure your device is compatible with the network card.
3. Most devices automatically detect drivers, and the product should work immediately after being connected. However, if you need to install them manually, use the link below to download and install the drivers or use the included disc.
<https://zenwire.eu/pl/i/Sterowniki-Drivers/157>
4. Follow the instructions in the driver installer to install the driver correctly.
5. The device is ready for use.

Warnings and Recommendations:

1. Under no circumstances should the device's casing be opened. Do not perform repairs that are not authorized by the manufacturer.
2. The product should not be used in conditions of high humidity; protect it from getting wet. Do not expose it to extremely high or low temperatures. Protect it from mechanical damage. It is recommended to use the device at room temperature.
3. Do not use the network card in a way that is inconsistent with its intended purpose, as this may result in damage.
4. The manufacturer is not responsible for the user's failure to follow the usage recommendations.
5. Keep the product and packaging materials away from children and animals. The product is not a toy.
6. Protect the product from excessive sun exposure.
7. The WiFi range depends on the environment in which the product is used; reinforced walls, surrounding elements, devices emitting radio and electromagnetic radiation, or long distances may result in weaker signal strength or interference. If you experience issues with operation, make sure these factors are not affecting the connection quality.

System Requirements:

- Windows XP / Vista / 7 / 8 / 8.1 / 10 / 11 and newer
- Mac OS 9 onwards / Linux

Email: sklep@zenwire.eu

Manufacturer: Zenwire Sp. Z.o.o. 60-685 Poznań, Wojciechowskiego 6B/133 Manufactured in PRC.



The symbol shown on products or accompanying documentation indicates that faulty electrical or electronic devices must not be disposed of with household waste. Proper handling for disposal, reuse, or recycling involves taking the device to a specialized collection point where it will be accepted free of charge. In some countries, the product can be returned to the local distributor when purchasing another device. Proper disposal of the device allows for the conservation of valuable resources and prevents negative impacts on health and the environment, which could be endangered by improper waste handling. Detailed information on the nearest collection point can be obtained from local authorities. Improper disposal of waste is subject to penalties provided by relevant local regulations

Business users in the European Union

If you need to dispose of electrical or electronic devices, please contact your nearest point of sale or supplier for additional information.

Disposal of waste outside the European Union

This symbol is only valid in the European Union. If you need to dispose of this product, please contact local authorities or the seller for information on the correct method of disposal

Simplified declaration of conformity

The manufacturer declares under its sole responsibility that this product to which this manual relates complies with the ROHS Directive 2011/65/EU and 2015/863 and the RED Directive 2014/53/EU.

Link to the manufacturer's declaration of conformity website:

<https://zenwire.eu/pl/i/Deklaracje-zgodnosci/148>

